

CTA LABEL 1

Aftercare/Cleaning Instructions

Regular Care

Protect from direct sunlight.
Vacuum regularly using low suction.
Rotate reversible cushions regularly.

Spot Cleaning

Treat spills and stains as soon as possible.
Gently scrape any soil or mop liquid from the surface of the fabric.
Do not scrub.
Apply proprietary cleaning agents strictly according to instructions to remove the residue of the spill.
Do not saturate the fabric or interior with water or other cleaning liquids.
May be spot cleaned with drycleaning solvent.

Cleaning

Do not remove cushion covers for separate cleaning, even though they do have zippers.
Clean with hot water extraction machine (hot).
Professional cleaning recommended.
Do not use dishwashing or laundry detergent.
Use only upholstery detergents.
Do not wet filling.
Dry in shade away from direct heat and sunlight.
Allow to dry thoroughly before re-use.

OR

Clean using on on-site drycleaning machine (P).
Professional cleaning only.
Do not wet filling with solvent.
Extract solvent thoroughly after application.
Wipe gently, do not rub.
CAUTION – exhaust solvent vapour outside building.
Provide adequate ventilation during cleaning and drying.
Allow to dry thoroughly before re-use.
Avoid use of room during drying period.

OR

May be shampoo cleaned using upholstery shampoo.
Do not use dishwashing or laundry detergents.
Do not wet filling.
Wipe gently, do not rub.
Dry in shade away from direct heat and sunlight.
Allow to dry thoroughly before re-use.